



DETAILS OF 20GA WITH REMOVABLE TRIGGER GROUP

EXPORT PRICE LIST APPLICABLE FROM JANUARY 1ST 2012 DETAILS OF 20GA MODELS WITH REMOVABLE TRIGGER GROUP

Note: When placing an order for spare parts, please indicate the part number, its full description and the serial number of the gun.

Part N.	Description	Part N.	Description	Part N.	Description
106	Link trigger release	177	Sear retainer sleeve	471	Connector pin for external selector
107	Lock trigger plate	178	Sear plunger	526	Pivot for adjustable rib
111	Locking piece top lever	205	Ejector spring plunger	527	Lock for adj. rib pivot
112	Cocking bar	206	Ejector spring	6162	Left hammer for coil springs
115	Pivot	207	Ejector lock	6166	Right and left hammer coil spring
116	Safety spring	307	Cocking bar cam	6172	Sear trip pivot pin
117	Cocking bar spring	309	Ejector sear spring	6178	Link retainer pin
118	Firing pin return spring	313	Ejector sear plunger	6193	Plunger for coil springs
119	Trigger plate lock pin	314	Ejector sear pin	21720	Choke tube (optional)
121	Top lever return spring	316	Ejector trip	23103	Top lever
122	Trigger plate lock cap	322	Catch bolt	23109	Right ejector trip rod
123	Cocking bar screw check	323	Cocking bar lock screw	23110	Left ejector trip rod
124	Safety spring screw	324	Spring for catch bolt	23113	Top firing pin
126	Safety botton pin and trigger plate lock pin	326	Latch plate	23114	Bottom firing pin
127	Link pin	327	Latch plate lever	23190	Coil springs file
129	Plunger trip	328	Lock screw for latch pl. lev. sp.	23200	Barrels (see guns price list)
134	Top lever lock pin return spring	329	Latch plate pin	23203	Right ejector
135	Top lever stop plate release pin	330	Return sping latch pl. lever	23204	Left ejector
137	Top lever stop plate rel. sp.plunger	331	Lock pin for latch plate lever	23308	Right ejector sear
145	Under safety	352	Stock bolt	23317	Left ejector sear
155	Trigger guard	353	Lock washer	23321	Iron forend (see guns price list)
156	Trigger	354	Plain washer	24104	Action bolt
157	Right release	355	Retainer guide	24105	Safety
158	Connector	356	Recoil pad	24136	Top lever stop plate
159	Right sear	358	Forend lock screw	24351	Stock (see guns price list)
160	Left sear	359	Forend lock bolt	24357	Forend (see guns price list)
161	Right hammer for flat springs	403	Adjustable trigger upper part	128/20	Lock pin for top lev. and fir. pin
162	Left hammer for flat springs	404	Adjustable trigger lower part	169/02	Left sear spring
163	Bridle	405	Adjustable trigger tab	175/03	Spring lock pin
164	Cocking foot	407	Trigger guard for adjustable trigger	212/03	Front sight
165	Right hammer flat spring	408	Sear trip pin	524/05	Adjustable rib tab 7x7
166	Left hammer flat spring	409	Adjustable trigger retaining pin	524/06	Adjustable rib tab 11x11
167	Connector spring	411	Adjustable trigger return spring	525/1	Spring for adj. rib tab
169	Right sear spring	412	Selector pin spring (optional)	6161B	Right hammer for coil springs
170	Connector plunger	414	Adjustable trigger tab pin	6226/01	Choke wrench (optional)
171	Connector pin	415	Adjustable trigger tab pin spring		
172	Connector post pin	419	Trigger for external selector		
173	Pivot sear trip - coil spring file pin rem. trigger group	420	External selector tab		
174	Bridle pin	421	Connector for ext. selector tab		
175	Sear retainer pin	422	Pin for ext. selector tab		
176	Trigger guard pin	458	Release for ext. selector		